

How to Clean and Disinfect Chromebooks

NEVER SPRAY ANY CLEANING SOLUTION DIRECTLY ON YOUR CHROMEBOOK. ALWAYS APPLY CLEANING SOLUTION TO A MICROFIBER CLOTH FIRST. AVOID BLEACH OR ANY OTHER HARSH CLEANING PRODUCTS, BRUSHES, OR PADS.

1. Power Down

COMPLETELY POWER DOWN CHROMEBOOK AND UNPLUG THE POWER CORD AND ANY PERIPHERALS, SUCH AS A MOUSE.



2. Optional!

USED COMPRESSED AIR TO REMOVE LARGER PIECES OF DIRT AND DUST IN KEYBOARD AND PORTS. USE A FEW SHORT BURSTS AND NEVER TURN CAN UPSIDE DOWN. THIS IS NOT NECESSARY FOR DISINFECTING.



3. Clean the Case and Keyboard.

WIPE DOWN THE CASE WITH A BLEACH-FREE ANTIBACTERIAL WIPE, THEN WHEN THE WIPE IS ALMOST DRY, WIPE DOWN THE KEYBOARD. TOO MUCH MOISTURE MAY CAUSE DAMAGE TO THE CHROMEBOOK.

You can also use a solution of 40% rubbing alcohol and 60% percent distilled water with a lint-free cloth.

4. Clean the screen

DISTILLED WATER OR THE RUBBING ALCOHOL/WATER SOLUTION WITH A LINT-FREE CLOTH IS THE BEST WAY TO CLEAN YOUR SCREEN. NEVER SPRAY THE SCREEN DIRECTLY. USE A SMALL AMOUNT OF PRESSURE TO REMOVE FINGERPRINTS OR SMUDGES, BUT NOT TOO MUCH.

SOURCE: [HTTPS://CHROMEUNBOXED.COM/5-STEPS-HOW-TO-CLEAN-DISINFECT-CHROMEBOOK-PREVENT-CORONAVIRUS-SPREAD-COVID19/](https://chromeunboxed.com/5-steps-how-to-clean-disinfect-chromebook-prevent-coronavirus-spread-covid19/)

powered by

 PIKTOCHART